

Please refer operation and installation manual of relevant indoor units before following the below steps.

INSTALLATION OF A MULTI SPLIT UNIT UP TO 3.5 kW (2 indoor units)

The multi-split unit will be installed according to the relevant installation instructions.

Fig 1
1.INDOOR UNIT -1
2.INDOOR UNIT-2
3.OUTDOOR UNIT




Fig. 1

ELECTRICAL CONNECTIONS BETWEEN OUTDOOR UNIT AND TWO INDOOR UNITS

INDOOR UNITS UP TO 3.5 kW

1. Use electrical cables according to paragraph 6 in the relevant installation manuals.
2. Make electrical connections of the indoor units according to paragraph 6 in the relevant installation manuals.
Identical for unit No. 1 and unit No. 2.
3. At the outdoor unit:
 - A. Wire the connector of the outdoor unit to the multiple wire power cables and insert it into the terminal end connector in the outdoor unit.
 - B. Connect the yellow/green earth wire to the ground screw.
 - C. Secure multiple wire power cable with the cable clamps.
4. The main power cable should be connected to a switch and, from there, to outdoor unit.

Attention! For multi-split units, remove power supply cord from indoor unit. Connect the main power supply to the outdoor unit only!





Fig 2

- Fig. 2**
1. Connector terminal end
 2. Connector cable end
 - A. Connection to indoor unit number 1
 - B. Connection to indoor unit number 2

Electrical cable to be connected via a separate switch to the mains.